

## AF-100 Mortised Bottom Doors

### Field Trimming

The standard mortised bottom on the AF-100 door series is designed to be field trimmed to accommodate floor condition without compromising the doors core. Maximum recommended amount that can be removed is 1-1/8". If you have an opening that requires door bottom trimming:

1. Determine the amount that needs to be removed. **1 1/8" MAXIMUM**
2. If the door is painted, take precautions to protect the finish.
3. Lay the door on saw horses and mark cut line.
4. Clamp straight edge in place for a saw guide.
5. Make cut using a 1/8"x 7 1/4" masonry circular saw blade. High speed steel and carbide tipped not recommended.
6. Factory painted doors are supplied with touch up kits. Touch up as necessary.
7. Re hang door and check clearance.

### Recommended Auto Door Bottom Mechanisms

The standard mortised bottom on the AF-100 door series is also designed to accept a number of mortised auto door bottom mechanisms. The list includes:

Pemko 434  
NGP 423  
Hager 743  
Zero 360A